



# Technical Bulletin

2400 Boston Street, Suite 200, Baltimore, Maryland 21224  
Phone: 410-675-2100 or 800-543-3840

Revised: 06/10/2019

## DAP® Quick Plug Hydraulic Cement

- For plugging and sealing holes in concrete and masonry
- Creates a watertight seal, even while water is flowing
- Can also be used as an anchoring cement

**Packaging:** 1.25kg, 5kg, 10kg  
**Color:** Gray  
**UPC Number:** 7079810060, 7079810070, 7079810080

### Company Information:

Manufactured for: DAP Canada, 475 Finchdene Square, Unit 5, Scarborough, ON. M1X 1B7

Usage Information: Call 888-DAP-TIPS or visit [dap.ca](http://dap.ca) & click on “Ask the Expert”

Order Information: 800-327-3339

Fax Number: 410-558-1068

Also visit the DAP website at [dap.ca](http://dap.ca)

### Product Description:

DAP® Quick Plug Hydraulic Cement may be used to stop running water through deep cracks and holes in concrete and masonry surfaces. DAP® Quick Plug Hydraulic Cement may be used for interior and exterior applications and when mixed properly, it creates a watertight seal in 3 to 5 minutes, even while water is flowing. DAP® Quick Plug Hydraulic Cement can also be used to anchor machinery and other equipment in concrete.

### Suggested Uses

- *For stopping water flow and permanently sealing deep cracks and holes in all grades of concrete.*
- *Also ideal for use as an anchoring cement.*

### Surface Preparation & Application

- Chisel holes to enlarge them by at least 1/4” and scrape clean. Remove any loose or chipped concrete. Make sure that the surface to be patched is damp.
- Add DAP® Quick Plug Hydraulic Cement to clear water in clean container mixing 3 parts powder to 1 part water. Stir the mixture until it reaches a putty-like paste. The mixture will begin to set in 3 to 5 minutes so only mix as much material as you can use in this time. Discard any material that has begun to set.
- Hold compound in your gloved hand until it becomes warm. Force it firmly into the hole and continue pressing it in place for 5 minutes. Within 3 to 5 minutes after setting, trim or brush away any excess cement for a smooth finish.

### **FOR BEST RESULTS**

- Always apply to a damp surface.
- Apply from the top of the opening down.

- Keep the patched area damp for several hours after the application.

**Physical & Chemical Characteristics:**

Working Time:	3 to 5 Minutes
Setting Time:	5 Minutes
Final Cure:	28 Days
MSDS No.:	71094

**Clean Up:**

Wash skin and hands with soap and water. Cured material must be scraped away

**Safety & Warranty Information:**

See product label and Safety Data Sheet (SDS) for health and safety information.

For an SDS, contact your supplier or visit [dap.ca](http://dap.ca)

If product fails to perform as directed, within one year from the date of purchase, call 1-888-DAP-TIPS, with your sales receipt and product container available, for replacement product or sales price refund.

DAP will not be liable for incidental or consequential damages.